

# ASSEMBLY

A9235 PRO SPEAK EVO  
FOR FLYON II



Remove the inner linings as indicated in the helmet user manual.



Place the right speaker (R) in its seat on the velcro.



Repeat the operations performed for the right (R) speaker for positioning the left (L).




Place the microphone base under the chinstrap.

# ASSEMBLY

A9235 PRO SPEAK EVO  
FOR FLYON II



5.



Adjust the position of the microphone by deforming the boom and insert it in the relative seat indicated by the symbol of the microphone on the shell left side.

**WARNING** check that the triangle on the microphone is facing the mouth.



6.

Before assembling the cheekpads, pass the remote control with its flat cable in the slot in the left cheekpad's pp plate.



7.

Place the BT controller in the designated slot on the back of the inner shell.



8.

House the cables behind the rear cushion.

# ASSEMBLY

A9235 PRO SPEAK EVO  
FOR FLYON II



Place the USB socket between the inner linings and the shell.



Fit the keypad on the left side (helmet on), approximately 5 mm from the lower edge of the shell using the provided adhesive. Make sure that there is no interference with the chin guard and full contact surface between the adhesive keypad and the outer shell.