ASSEMBLY INSTRUCTION

UUST SPEAK WIRELESS COMMUNICATION





Remove the cheekpads as indicated in the communicator's instruction manual.



Place the right speaker (R) in its seat after applying the adhesive round shaped Velcro included in the package.



Repeat the operations performed for the right (R) speaker for positioning the left (L).



Pass the flat cable of the remote control between the neckroll's pp plate and the shell. The remote control must remain accessible outside the helmet.

ASSEMBLY INSTRUCTION

UUST SPEAK

***** Bluetooth



Position the microphone underneath the chinstrap by housing the boom in its seat.



Adjust the microphone's position by deforming its boom.

WARNING: check that the triangle on the microphone is facing the mouth.



House the cable that connects the right speaker to the left between the rear cushion and the neckroll.



Assemble the cheekpads. Place the USB socket between the cheekpad and the neckroll.

ASSEMBLY INSTRUCTION





Stick the remote control on the side of the shell verifying the correct adhesion.