ASSEMBLY INSTRUCTION

UUST SPEAK WIRELESS COMMUNICATION



Remove the inner linings as indicated in the communicator's user manual.



Place the right speaker (R) in its seat on the velcro.



Repeat the operations performed for the right (R) speaker for positioning the left (L).



Place the microphone base under the chinstrap.

ASSEMBLY INSTRUCTION

UUST SPEAK

***** Bluetooth



Adjust the position of the microphone by deforming the boom and insert it in the relative seat indicated by the symbol of the microphone on the shell left side.

WARNING: check that the triangle on the microphone is facing the mouth.



Before assembling the cheekpads, pass the remote control with its flat cable in the slot in the left cheekpad's pp plate.



Assemble the inner linings making sure that the microphone, remote control and USB cable are accessible from outside the helmet.



House the cable that connects the right speaker to the left behind the rear cushion.

ASSEMBLY INSTRUCTION

UUST SPEAK WIRELESS COMMUNICATION



Place the USB socket between the inner linings and the shell.



Stick the remote control on the side of the shell verifying the correct adhesion.