

ASSEMBLY INSTRUCTION

JUST SPEAK
WIRELESS COMMUNICATION
Bluetooth® **EVO**



Remove the cheekpads as indicated in the communicator's instruction manual.



Place the right speaker (R) in its seat after applying the adhesive round shaped Velcro included in the package.



Repeat the operations performed for the right (R) speaker for positioning the left (L).



Pass the flat cable of the remote control between the neckroll's padding plate and the shell. The remote control must remain accessible outside the helmet.

ASSEMBLY INSTRUCTION

JUST SPEAK
WIRELESS COMMUNICATION
Bluetooth® **EVO**



Position the microphone by passing the boom under the chinstrap that will be housed in its seat.



Adjust the microphone's position by deforming its boom.

WARNING: check that the triangle on the microphone is facing the mouth.



House the cable that connects the right speaker to the left between the rear cushion and the neckroll.



Assemble the cheekpads. Place the USB socket between the cheekpad and the neckroll.

ASSEMBLY INSTRUCTION

JUST SPEAK
WIRELESS COMMUNICATION
Bluetooth® **EVO**



Stick the remote control on the side of the shell verifying the correct adhesion.