ASSEMBLY INSTRUCTION

UUST SPEAK

Bluetooth



Remove the inner linings as indicated in the communicator's user manual.



Place the right speaker (R) into the seat on the EPS using the velcro on the back of the speaker.



Repeat the operations for the right speaker (R) to position the left (L).



Attach the microphone base to the linings's side plate with the Velcro included in the package. Place the microphone boom over the automatic button.

ASSEMBLY INSTRUCTION

UUST SPEAK WIRELESS COMMUNICATION





Adjust the microphone's position by deforming its boom.

WARNING: check that the triangle on the microphone is facing the mouth.



Assemble the inner linings making sure that the microphone, remote control and USB cable are accessible from outside the helmet.



Stick the remote control on the side of the shell verifying the correct adhesion.