ASSEMBLY





Remove both cheek pads and place the connecting cable between the left and right speaker under the rear cushion.



Place the right speaker (R) behind the cheek pad at the holes using the velcro on the back of the speaker.



Repeat the operations for the right speaker (R) to position the left (L).



Snap in the cheek pad's buttons on both sides paying attention to not "pinch" the cables.

ASSEMBLY





Attach the microphone on the comfort padding with the Velcro on the back of the microphone base.



Adjust the microphone's position by deforming its boom.

WARNING check that the triangle on the microphone is facing the mouth.



Place the USB socket between the removable cheek pads and the comfort padding.



Stick the remote control on the side of the shell verifying the correct adhesion.