

# ASSEMBLY INSTRUCTION

JUST SPEAK  
WIRELESS COMMUNICATION  
Bluetooth® **EVO**



Remove the cheekpads as indicated in the communicator's instruction manual.



Place the right speaker (R) in its seat after applying the adhesive round shaped Velcro included in the package.



Repeat the operations performed for the right (R) speaker for positioning the left (L).



Place the microphone in the seat in the inner cover of the chinguard.

**WARNING:** check that the triangle on the microphone is facing the mouth.

# ASSEMBLY INSTRUCTION

JUST SPEAK  
WIRELESS COMMUNICATION  
Bluetooth **EVO**



House the cable that connects the right speaker to the left behind the rear cushion.



Before assembling the cheekpads, pass the remote control with its flat cable in the slot in the left cheekpad's padding plate.



Place the USB socket between the removable cheekpads and the rear cushion.



Stick the remote control on the side of the shell verifying the correct adhesion.